
Properties of Wide BandGap Materials

INTRODUCTION

Future Radar Design Requires Higher Power RF Amplifiers



Surface Navy Radar



Aperture size constraints:

S-band: 32 m²

X-band: 10 m²

- NAVY REQUIREMENTS FOR LONGER RANGE DETECTION, DISCRIMINATION & COUNTERMEASURES CHALLENGE FUTURE RADAR DESIGNS.
- NAVAL ARCHITECTURE LIMITS ANTENNA APERTURE SIZE.
 - ⇒ REQUIRE **HIGHER POWER RF AMPLIFIERS**
- CANNOT BE PROVIDED BY CURRENT GaAs TECHNOLOGY.
- NEW HIGH POWER AMPLIFIER TECHNOLOGIES NEEDED TO MEET FUTURE NAVY REQUIREMENTS.
- THESE REQUIREMENTS CAN ONLY BE MET USING **WIDE BANDGAP POWER AMPLIFIERS.**

Background

- Large-area GaN and SiC substrates required for next-generation high power/high frequency applications (e.g., RF power amplifiers) in critical Navy systems.
 - 2-3" SiC wafers commercially available.
 - 4" SiC wafers under development.
 - 2" GaN wafers under development.
- Structural defects (dislocations, micropipes, etc.), lattice imperfections (vacancies, interstitials, antisites), residual impurities (Si, O, C, B, N, etc.), and dopants (Si, Mg, V, etc.) play significant roles in **electronic properties** of wide bandgap semiconductors.
- Need to develop contactless methods to screen/assess wafers for crystalline quality and conductivity-type in a production line environment.

Structural Characterization


X-ray Topograph (M. Dudley, SUNY Stony Brook)

GB - Grain Boundary

M - Micropipe


MG - Micropipe Groups

E - screw dislocation




SiC PROPERTIES

Low Temperature Photoluminescence




- Emission near 3.2 eV due to N-bound excitons.
 - Narrow linewidths reflect high crystallinity of samples.
- Strong for n-type and undoped (SI) samples; weak for V-doped sample.




- Different deep emission bands.
 - Strong band near 2.2 eV from n-type sample (green).
 - Weak band near 2.3 eV from undoped (SI) sample (blue).
 - Strong structured band from V-doped sample (red).

Non-destructive Infrared Assessment of Impurities




- n-type sample absorbs strongly in region of 1s-2p (N donor) electronic excitation transitions.
- High-resistivity sample absorbs only weakly.




- Feature near 631 cm^{-1} due to N localized gap mode.
 - intensity proportional to N concentration on C site.
 - work underway to obtain calibration standard.

Electron Paramagnetic Resonance (EPR)




- “Fingerprint” 3-line spectrum of N observed ($s=1/2$, $I=1$).
- $N_c = 2.2 \times 10^{17} \text{ cm}^{-3}$; $N_h = 1.4 \times 10^{17} \text{ cm}^{-3}$.




- Residual shallow Boron acceptors.
 - Hexagonal site indicated by quartets of arrows ($I=3/2$); $B_h \sim 2.2 \times 10^{14} \text{ cm}^{-3}$.
 - Cubic site (weak) indicated by dashed rectangles.

PL/ODMR of Large-Area SiC Substrates

PL




ODMR



- **ODMR:** Combines PL + EPR - - probes optically-excited states.
- Broad PL band observed at 2.4 eV (weak PL < 2.0 eV) from SI 6H-SiC.
- Three defects identified in as-grown wafer.
 - N donors on hex. + two cubic sites.
 - C vacancies + Si_C anti-sites (as reported from EPR of e⁻-irradiated 6H-SiC).


GaN PROPERTIES

High-Resolution PL of Free-Standing HVPE GaN





- Very sharp bandedge emission due to free and impurity-bound excitons observed at low temperature.
- Material exhibits highest room-temperature electron mobilities ($\sim 1350 \text{ cm}^2/\text{V}\cdot\text{sec}$) reported to date.

Non-destructive Infrared Assessment of Impurities



- Donors and acceptors in semiconductors have characteristic optical absorption signatures.
- Spectral position is unique to a specific impurity and absorption intensity is proportional to concentration.
- Absorption features in the IR transmission plot are due to three donors.

Optically-Detected Magnetic Resonance of High-Resistivity GaN




- In addition to sharp band-edge emission (FX), two broad PL bands at 2.2 and 3.0 eV (“optical signature”) are observed from HR GaN.
- ODMR reveals that shallow donors ($g=1.951$) are active in both 2.2 and 3.0 eV bands.
- Four additional defects ($g=1.958$, 1.978, 1.992, and 2.022) attributed to residual donors and acceptors are also found.

PHOTOIONIZATION SPECTROSCOPY OF DEFECTS IN WIDE BANDGAP ELECTRONIC DEVICES

CURRENT COLLAPSE IN WIDE BANDGAP DEVICES


- SOME DEVICES EXHIBIT OUTPUT DEGRADATION AFTER TURN-ON.
 - Due to MATERIAL DEFECTS.
- DEFECTS CAUSE **“Current Collapse”**.
 - Defect **traps** mobile charge carrier - **reduces device current & power.**



- **LIGHT** WILL FREE (PHOTOIONIZE) CARRIERS FROM TRAPS AND **RESTORES DEVICE PROPERTIES.**
- \Rightarrow USE LIGHT ABSORPTION PROPERTIES OF DEFECTS TO **IDENTIFY & QUANTIFY** DEFECTS.

Photoionization Spectroscopy of Defects (Traps)

- NEW technique developed at NRL
 - o Dependence of defect light absorption on wavelength (color).
 - o Spectrum determines **unique fingerprint of each defect**.
 - o Provides method to determine **concentrations of defects**.
 - o Leads to method of **defect identification**.
 - o Essential information for defect **elimination**.



Defect Identification from Photoionization Spectroscopy

- Defect incorporation affected by material growth conditions.
- Variation of Trap1 & Trap2 concentrations with material growth pressure:
 - Concentration of Trap2 TRACKS concentration of **CARBON**.
 - **Trap2 is carbon-related defect.**
 - Reduction of carbon expected to reduce this effect.
 - Trap1 concentration varies similar to **structural defects**.
 - Current studies probing this relationship.

